



# ST. VINCENT AND THE GRENADINES

## MARITIME ADMINISTRATION

### CIRCULAR N° SOL 060

#### **INTERIM GUIDANCE ON THE AUTO FUNCTION OF BRIDGE NAVIGATIONAL WATCH ALARM SYSTEMS (BNWAS)**

**This Circular should be read in conjunction with  
Circular SOL 042**

**TO:** **SHIPOWNERS, SHIPS' OPERATORS AND  
MANAGERS, MASTERS, FLAG STATE SURVEYORS  
AND CLASSIFICATION SOCIETIES**

**APPLICABLE TO:** All ships fitted with BNWAS

**EFFECTIVE AS FROM:** Date of this Circular

10<sup>th</sup> July 2014

The IMO has issued interim guidance as stipulated in Circular MSC.1/Circ.1474) stating that the automatic operational mode on bridge navigational watch alarm systems (BNWAS), if available, should not be used.

This is an interim measure pending a revision of the performance standards for BNWAS contained in IMO Resolution MSC.128 (75).

The guidance follows concerns raised over the use of the automatic mode at a meeting of the IMO's NAV Sub-Committee and the resulting conclusion that the automatic mode is not usable on a ship compliant with the SOLAS Convention.

Owners and operators should ensure that Masters of ships fitted with a bridge navigational watch alarm system are aware of this information.

#### **Annex to this Circular:**

- MSC.1/Circ.1474

---

4 ALBERT EMBANKMENT  
LONDON SE1 7SR  
Telephone: +44 (0)20 7735 7611 Fax: +44 (0)20 7587 3210

MSC.1/Circ.1474  
23 May 2014

**GUIDANCE ON THE BRIDGE NAVIGATIONAL WATCH  
ALARM SYSTEM (BNWAS) AUTO FUNCTION**

1 The Maritime Safety Committee, at its ninety-third session (14 to 23 May 2014), with a view to providing more specific guidance on the automatic function specified in resolution MSC.128(75) – *Performance standards for a bridge navigational watch alarm system (BNWAS)*, approved the guidance, prepared by the Sub-Committee on Safety of Navigation at its fifty-ninth session (2 to 6 September 2013), as set out in the annex.

2 Member Governments are invited to use the guidance as an *interim* measure until such time as the performance standards can be reviewed and revised and, furthermore, bring this guidance to the attention of all parties concerned.

\*\*\*

---

ANNEX

**GUIDANCE ON THE BRIDGE NAVIGATIONAL WATCH  
ALARM SYSTEM (BNWAS) AUTO FUNCTION**

1 SOLAS regulation V/19.2.2.3 requires the provision of a Bridge Navigational Watch Alarm System (BNWAS), which shall be in operation whenever the ship is under way at sea, whilst SOLAS regulation V/18 requires BNWAS to conform to appropriate performance standards not inferior to those adopted by the Organization (i.e. resolution MSC.128(75)).

2 Resolution MSC.128(75) – *Performance standards for a bridge navigational watch alarm system (BNWAS)*, section 4.1.1.1 states that "*the BNWAS should incorporate the following operational modes:*

- Automatic (Automatically brought into operation whenever the ships heading or track control system is activated and inhibited when this system is not activated)
- Manual ON (In operation constantly)
- Manual OFF (Does not operate under any circumstances)".

3 At the fifty-fifth session of the NAV Sub-Committee, concerns were raised with respect to the use of the Automatic mode and NAV 55 concluded that the Automatic mode of the performance standard was therefore not usable on a ship compliant with the SOLAS Convention. It was considered that it would not be possible to change the performance standards before the date at which the carriage requirements came into force (1 July 2011). In order to conform with the performance standards, therefore, equipment would include the Automatic mode, despite that this operational mode should not be used on ships which are subject to the SOLAS Convention.

4 From the operational point of view, automatic interface with activation of the ship's heading or track control system (HCS/TCS) is a superfluous function because SOLAS regulation V/19.2.2.3 requires the BNWAS to be in operation whenever the ship is under way at sea. This creates an inconsistency between SOLAS regulation V/19.2.2.3 and the "Automatic mode" provisions in the performance standard. In addition, from the technical point of view, it is noted that this issue is also addressed in the "note" to section 3.1.1 of IEC 62616:2010 – Maritime navigation and radiocommunication equipment and systems – Bridge navigational watch alarm system (BNWAS), which states:

*"NOTE: The Automatic mode is not suitable for use on a ship conforming with regulation SOLAS V/19.2.2.3 which requires the BNWAS to be in operation whenever the ship is underway at sea".*

5 Accordingly, as an *interim* measure and pending a revision of the *Performance standards for a bridge navigational watch alarm system (BNWAS)* – (resolution MSC.128(75)), the automatic operational mode, if it is available, should not be used.