KC#941

HORIZ. GIRDER

Figure D.5.1
Advanced Buckling Assessment for longitudinal strength



Notes

1. SP – M1 denotes stiffened panel – buckling strength assessed using Method 1
2. SP – M2 denotes stiffened panel – buckling strength assessed using Method 2



1) Is it OK to define a buckling panel like 'A1' ?
2) How about 'A2' ? Is it possible?
3) I think 'SP-M1' may be used for the panel 'A'(A1 or A2) and 'UP-M2' for the panel 'B'. Is it right?